

tekmar[®] - Service Bulletin

Operation of Application A 370-6 07/95

SB 011

09/96

The Domestic Hot Water operation as shown in application drawing A 370-6 dated 07/95, does not work correctly as wired. The reason the DHW demand is connected to both the House Control 370 as well as the Two Stage Boiler & DHW Control 252 is to permit DHW priority operation of the system.

If no boiler sensor is connected to the House Control 370, the DHW Pmp/Vlv contacts (20 & 21) will not operate even though a DHW Demand is applied. However, the DHW Demand light turns on. The boiler contacts (18 & 19) will also not operate in this configuration. When no boiler sensor is connected to the House Control 370, the Min. Boiler Supply dial must be turned off.

We have revised the application drawing A 370-6 05/95 to A 370-6 dated 10/96 to ensure correct operation of the DHW section. The application drawing will be included in the next mail update.

Find enclosed updated Application drawing A 370-6 10/96

Regards,

Eric Balt
Sales & Marketing